

IR Remote Controller Key HEX Code

CH-	CH	CH+
PREV	NEXT	PLAY/PAUSE
-	+	EQ
O	100+	200+
1	2	3
4	5	6
7	8	9

